

Darwin Terminal

Darwin Terminal is the single supply point for fuels distribution amongst the industry servicing the northern area of central Australia. Sited at the East Arm within the Port of Darwin, its location provides efficient access to coastal shipping resupplying the terminal with fuels.

By road, Darwin Terminal is about 20km south east of the city centre and can be accessed via Berrimah Rd from the Stuart Highway.

Terminal Overview

- Total tankage for all fuel products exceeds 100 ML.
- Has 5 loading bays for fuels

Operating Details

- Open 24 hours per day, 7 days a week, 365 days a year

Product Availability

- ULP, 95 PULP and Diesel

Facilities

- Driver facilities include:
 - Lunch room, shower, toilet

Contact Information

Address

780 Berrimah Road,
East Arm, Darwin, NT, 0828

Contact number

08 8999 9100

